

Function	IO Type	Washing Machine	Washer Dryer	Dryer	Cleaning Robot	Oven	Coffee Machine	Cooktop
<b>Controlling</b>								
Power On	Digital Output				x	x	x	x
Power Off	Digital Output							x
Set To Standby	Digital Output				x	x	x	
Start Specific Program	Digital Output	Cotton, Mix,Easy-Care	(see Washer & Dryer)	Cotton, Synthetic,Mix	Clean All, Go Home	Preheating	Coffee, Espresso,Cappuccino	
Start Selected Program	Digital Output	x	x	x	x	x	x	
Stop Running Program	Digital Output	x	x	x	x	x	x	
Pause Running Program	Digital Output	x	x	x	x	x		
Resume Paused Program	Digital Output	x	x	x	x	x		
Set Target Temperature	Analog Output							
Toggle Supercooling	Digital Output							
Toggle Superfreezing	Digital Output							
Toggle Eco Mode	Digital Output							
Toggle Sabbath Mode	Digital Output							
Toggle Vacation Mode	Digital Output							
Toggle Fresh Mode	Digital Output							
Set Current Map	Analog Output				x			
Toggle Functional Light	Digital Output							
Set Functional Light Brightness	Analog Output							
Toggle Ambient Light	Digital Output							
Set Ambient Light Brightness	Analog Output							
<b>Monitoring</b>								
Operation State	Analog Input	x	x	x	x	x	x	x
Power State	Analog Input				x	x	x	x
Remote Start Allowance State	Digital Input	x	x	x		x	x	
Battery Level	Analog Input				x			
Remaining Program Time	Analog Input	x	x	x		x	x	
Elapsed Program Time	Analog Input				x	x		
Program Progress	Analog Input	x	x	x		x	x	
Program Aborted	Digital Input	x	x	x	x	x		
Program Finished	Digital Input	x	x	x	x	x		x
Alarm Clock Elapsed	Digital Input					x		x
Preheating finished	Digital Input					x		x
Bean Container Empty	Digital Input						x	
Water Tank Empty	Digital Input						x	
Drip Tray Full	Digital Input						x	
Door Alarm Freezer	Digital Input							
Door Alarm Refrigerator	Digital Input							
Temperature Alarm Freezer	Digital Input							
Empty Dust Box And Clean Filter	Digital Input				x			
Cleaning Robot Stuck	Digital Input				x			
Docking Station Not Found	Digital Input				x			
Door State	Analog Input	x	x	x		x		
Last Selected Map	Analog Input				x			
Lost	Digital Input				x			
Lifted	Digital Input				x			

